




制图:

审核:

KM0408006 GEAR BOX
VERSION: 20150609

SPARE PARTS LIST OF KM0408006 (MACHINERY)


PAGE:1

Fig.NO.	PART NO.	DESCRIPTION	QTY	Fig.NO.	PART NO.	DESCRIPTION	QTY
M1		CLUTCH DRUM	1	M26		SCREW M5*30	2
M2		BEARING 6301RS	2	M27		AXIS B	1
M3		GEAR BOX PART A	1	M28		GEAR B	1
M4		AXIS A	1	M29		PLAT WASHER	1
M5		PIN 5*10	2	M30		SCREW M6*15	1
M6		GASKET	1	M31		GEAR BOX ASSY.	1
M7		GEAR BOX PART B	1	M32		LATCH	1
M8		BEARING 6201RS	3	M33		COTTER	1
M9		GASKET	1	M34		DRILL	1
M10		CIRCLIP	2	M35		THROTTLE	1
M11		GEAR A	1	M36		SCREW M5*30	2
M12		AXLE	1	M37		STOP SWITCH	1
M13		PIN 5*12	2	M38		CABLE	1
M14		GEAR BOX PART C	1	M39		BELLOWS	1
M15		SCREW M5*45	4	M40		RUBBER HANDLE A	1
M16		BEARING 6004RS	1	M41		TRIGGER	1
M17		CIRCLIP	1	M42		HANDLE PROTECTOR	1
M18		OIL SEAL 20*45*7	1	M43		TORSIONAL SPRING	1
M19		WASHER	1	M44		PLASTIC LATCH	1
M20		CUSHION	1	M45		SPRING	1
M21		WAVE WASHER	5	M46		SPRING SEAT	1
M22		PLAT WASHER	5	M47		SQUARE NUT	2
M23		SCREW M6*25	5	M48		CIRCLIP	1
M24		SCREW M5*25	2	M49		FRAME	1
M25		PIN	2	M50		RUBBER HANDLE B	1

[illegible]

1E244F-2

KM0408006 ENGINE
VERSION:20150609



制图:

审核:

SPARE PARTS LIST OF KM0408006 (ENGINE PART)

PAGE:1

Fig. NO.	PART NO.	DESCRIPTION	QTY	Fig. NO.	PART NO.	DESCRIPTION	QTY
KM0408006-E1	1E36FE. 9-3	SCREW	1	KM0408006-E26		CRANK CASE	1
KM0408006-E2	1E36FE. 9-4	RATCHET	1	KM0408006-E27			
KM0408006-E3	1E36FE. 9-1	STARTER ROPE REEL	1	KM0408006-E28		PIN B4*10	2
KM0408006-E4	1E36FE. 9-5	STARTER ROPE	1	KM0408006-E29	1E40F-5. 9	OIL SEAL	1
KM0408006-E5	1E36FE. 9-7	RECOIL SPRING	1	KM0408006-E30	GB/T9074. 4	SCREW M5*30	4
KM0408006-E6	1E36FE. 9-8	STARTER BODY	1	KM0408006-E31	1E40F-5. 3-	FLY WHEEL	1
KM0408006-E7	1E40FP-3Z. 4- 2	STARTER HANLE	1	KM0408006-E32	GB/T6177. 1	NUT M8	1
KM0408006-E8			1	KM0408006-E33	1E40F-5. 3-	IGNITION	1
KM0408006-E9	GB/T9074. 4	SCREW M5*20	5	KM0408006-E34	GB/T9074. 1 3	BOLT M5*20	2
KM0408006-E10	1E36FE. 9-2	STARTER POLE	2	KM0408006-E35	SG230-2	CORD COMP.	1
KM0408006-E11	1E40F-5A-2	RUBBER CUSHION	1	KM0408006-E36	1E36F-3	WASHER B	2
KM0408006-E12	1E40F-5-10	START GASKET	1	KM0408006-E37	1E40F-5. 6- 1	SPRING	1
KM0408006-E13	1E36FE. 7	START REEL	1	KM0408006-E38	1E40F- 5. 6. 1	EXPANDER	2
KM0408006-E14	1E36FE. 9-6	SPRING	1	KM0408006-E39	1E40F-5-11	WASHER	2
KM0408006-E15				KM0408006-E40	1E40F-5-12	SCREW PIN	2
KM0408006-E16				KM0408006-E41		FAN COVER	1
KM0408006-E17				KM0408006-E42	GB/T9074. 1 3	BOLT M5*25	4
KM0408006-E18	1E36F. 2	OIL SEAL	1	KM0408006-E43	1E44F- 2A. 2-3	BEARING	1
KM0408006-E19		CRANK CASE	1	KM0408006-E44	1E40F- 03. 02. 01	RING	2
KM0408006-E20	1E40F-5. 8-4	CRANK CASE GASKET	1	KM0408006-E45	1E44F- 2A. 2-1	PISTON	1
KM0408006-E21	GB/T276	BEARING 6206/P5	2	KM0408006-E46	1E44F- 2A. 2-2	PISTON PIN	1
KM0408006-E22	1E44F-2A. 2. 1	CRANK SHAFT	1	KM0408006-E47	GB/T9074. 4	BOLT M5*12	3

KM0408006-E23	GB/T1099	KEY 3*13	1	KM0408006-E48	1E44F-2A. 2-4	PISTON RING	2
KM0408006-E24	GB/T119	PIN B5*12	2	KM0408006-E49	1E40F-5-6	CYLINDER GASKET	1
KM0408006-E25	1E40F-5A. 4. 2-1	RUBBER CUSHION	2	KM0408006-E50	1E44F-2A-1	CYLINDER	1
SPARE PARTS LIST OF KM0408006 (ENGINE PART) PAGE:2							
KM0408006-E51	GB/T70. 1	SCREW M5*20	4	KM0408006-E76	GB/T70. 1	SCREW M5*55	2
KM0408006-E52		GUIDE COVER ASSY.	1	KM0408006-E77	1E34F. 1-1	AIR FILTER	1
KM0408006-E53	L6 (LD)	SPARK PLUG	1	KM0408006-E78			1
KM0408006-E54	1E40F-3A. 8-2	SPRING	1	KM0408006-E79			
KM0408006-E55	1E34F. 5-3	PLUG CAP	1	KM0408006-E80		OUTSIDE COVER	1
KM0408006-E56	1E34F. 5-2	CAP	1	KM0408006-E81	GB/T9074. 4	SCREW M5*16	3
KM0408006-E57		COVER	1	KM0408006-E82	1E40F-5. 11	STARTER	1
KM0408006-E58	1E40F-5. 3-1	PLUG	1	KM0408006-E83	1E34F. 9. 2-3	FUEL FILTER	1
KM0408006-E59	1E40F-5-5	MUFFLER GASKET	1	KM0408006-E84	1E40F-5A. 4. 2-2	FUEL PIPE	1
KM0408006-E60	1E40F-5. 2	MUFFLER	1	KM0408006-E85	1E36FF. 8. 1-1	PLUG	1
KM0408006-E61	1E40F-5-13	BOLT	2	KM0408006-E86	1E40F-5A. 4. 2-1	FUEL PIPE	1
KM0408006-E62			2	KM0408006-E87		FUEL TANK	1
KM0408006-E63		MUFFLER COVER	1	KM0408006-E88	1E32FL. 6. 2-1	FUEL TANK LID	1
KM0408006-E64	1E40F-5-2	ADMITTING PIPE GASKET	1	KM0408006-E89	CG420. 1. 3. 1-2	O RING	1
KM0408006-E65	1E40F-5A. 2	ADMITTING PIPE	1	KM0408006-E90	EB415. 4. 1. 1-1	INLET	1
KM0408006-E66	1E40F-5A-1	CARBURETOR GASKET	1	KM0408006-E91	1E32FL. 6. 2-2	INSIDE COVER	1
KM0408006-E67	1E44F-2A. 1	CARBURETOR	1	KM0408006-E92	1E32FL. 6. 2-3	LID	1
KM0408006-E68			1	KM0408006-E93	1E32FL. 6. 2-4	CHAIN	1
KM0408006-E69			1	KM0408006-E94		FUEL TANK LID COMP.	1
KM0408006-E70			1	KM0408006-E95	CG430-2	STAND	1

KM0408006-E71		INSIDE COVER	1	KM0408006-E96	GB/T9074.1 3	SCREW M5*30	2
KM0408006-E72		CHOKE	1	KM0408006-E97		CHOKE SWITCH	1
KM0408006-E73			1	KM0408006-E98		STARTER PROTECTOR	1
KM0408006-E74	GB/T97.1	WASHER 5	2				
KM0408006-E75	GB/T93	WASHER 5	2				