



9. EXPLOSIVE VIEW AND PARTS LIST FOR KM0407808B ENGINE PART



NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.
1	GB/T67	Screw M5X12	1	32	1E34F-11	Washer B	2	63	GB/T6177.1	Nut M5	2	68-26		Cover Pump	1
2	1E36F.1-4	Washer	1	33	1E34F.10-1	Spring	1	64	1E31F-3	Muffler Cover	1	68-27	GB/T818	Screw M3×22	4
3	1E36F.1-3	Start Rope Reel	1	34	1E34F.10.1	Expander	2	65	1E36F-2-2	Gasket	1	69	1E34F.1-2	Choker Handler	1
4		Rope (φ3.5X800)	1	35	1E34F-13	Washer	2	66	1E36F-2A-2	Admitting Pipe	1	70	1E34F.1.1-1	Pipe	1
5	1E36F.1-2	Recoil Spring	1	36	1E34F-12	Screw Pin	2	67	1E36F-2A-1	Gasket	1	71	1E34F.1-7	Stop Ring	
6	1E36F.1.1.1	Start Cover Ass'y	1	37	1E31F.6-2	Fan Cover	1	68	1E33F.2	Carburetor	1	72	1E34F.1.1	Cleaner Inside Cover	1
7	1E36F.1-1	Starter Handle	1	38	GB/T9074.13	Bolt M5×16	4	68-1		Thimble	1	73	GB/T9074.4	Screw M5X50	2
8	1E36F.1-5	Ring	1	39	1E40F-3A.9	Clip	1	68-2		Main Needle	1	74	1E36F.1	Starter	1
9	GB/T9074.4	Screw M4×20	3	40	1E31F.4.1	Bearing	1	68-3		Screw	1	75	1E34F.1-3	Choker	1
10	GB/T97.1	Washer B	1	41	1E31F.4-3	Ring	2	68-4	GB/T823	Screw M3×10	2	76	GB/T845	Screw ST4.2X12-F-II	1
11	GB/T6170	Nut M8	1	42	1E33F.1.2	Piston	1	68-5		Swivel	1	77	1E34F.1-1	Filter	1
12	1E46FP.4-2	Start Claw	1	43	1E31F.4-2	Piston Pin	1	68-6	GB896	Ring 3.5	1	78	1E34F.1-4	Cleaner Outside Cover	1
13	1E36F.1.2-2	Start Spring	1	44	1E31F.8-3	Gasket	1	68-7		Turn Frame	1	79	1E34F.1.2	Screw	2
14	1E36F.1.2-1	Start Reel	1	45	1E33F.1-1	Piston Ring	2	68-8		Airproof Ring	1	80	GB/T9074.4	Screw M5X16	1
15	GB/T896	Stop Ring 4	1	46	1E31F-2	Gasket	1	68-9	GB/T6172	Nut M6	1	81	1E34F.9.2-3	Cleaner Cover	1
16	1E36F.2	Oil-Seal	2	47	1E33F-1	Cylinder	1	68-10		Nut Adjuster	1	82	1E31F.7.1-2	Fuel Pipe	1
17	1E31F.8-2	Crank Case	1	48	GB/T770.1	Screw M5×16	4	68-11		Bracket	1	83	1E36FF.8.1-1	Plug	1
18	GB/T276	Bearing 6201/PS	2	49	1E31F.5	Guide Cover ASS'Y	1	68-12		Fixed Board	1	84	1E31F.7.1-1	Fuel Pipe	1
19	1E33F.1.1	Crank Shaft	1	50	L6(LD)	Spark Plug	1	68-13		Spring	1	85	1E31F.7-1	Fuel Tank	1
20	GB/T1099	Key 3X5X13	1	51	1E40F-3A.8-2	Spring	1	68-14		Column	1	86	1E32FL.6.2-1	Fuel Tank Lid	1
21	GB/T119	Pin B4×10	4	52	1E34F.5-3	Plug Cap	1	68-15		Ring	1	87	CG420.1.3.1-2	Gasket	1
22	1E31F.8-1	Crank Case	2	53	1E34F.5-2	Cap	1	68-16		OverBody	1	88	EB-41S.4.1.1-1	Airscoop	1
23	1E31F.6-1	Flash Pan	1	54	1E40F-5.3-1	Plug	1	68-17		O Ring	1	89	1E32FL.6.2-2	Inside Cover	1
24	GB/T9074.4	Screw M5X25	3	55	1E33F-1	Cover	1	68-18		Pinhole	1	90	1E32FL.6.2-3	Casing	1
25		MAGNETO ROTOR COMP.	1	56	GB/T9074.4	Screw M5X18	1	68-19		Gasket,Pump	1	91	1E32FL.6.2-4	Chain	1
26	GB/T859	WasherB	1	57	1E31F-5	Gasket	2	68-20		Diaphragm,Pump	1	92	1E32FL.6.2	Lid Ass'y	1
27	GB/T97.1	WasherB	1	58	1E31F.2	Muffler	1	68-21		Mid-body	1	93	1E31F-6	Stand	1
28	GB/T6170	Nut M8	1	59	GB/T9074.4	Screw M5X20	2	68-22		Gasket Diaphragm	1	94	1E31F-4	Rubber Cover	1
29		IGNITION COIL COMP.	1	60	GB/T9074.4	Screw M5X12	1	68-23		Diaphragm	1	95			
30	1E31F.3.1	Cord COMP.	1	61	1E36F-19	Label	1	68-24		Body Purge	1	96			
31	GB/T9074.13	Bolt M5×20	2	62	1E34F-14	Bolt	1	68-25		Pump Priming	1	97			

KH04078086-E-25

10. EXPLOSIVE VIEW AND PARTS LIST FOR KM0407808B PUMP PART



NO.	Part No.	PART NAME	QTY	NO.	Part No.	PART NAME	QTY	NO.	Part No.	PART NAME	QTY
1	KM0407808B-01	Clip-S	1	31	KM0407808B-31	Washer 06	1	69	KM0407808B-69	Cylinder	1
2	KM0407808B-02	Overflow hose(1.5m)	1	32	KM0407808B-32	Engine stand	1	70	KM0407808B-70	Clip-L	1
3	KM0407808B-03	Pressure valve rod	1	33	KM0407808B-33	Joint-s 22*14.4	1	71	KM0407808B-71	Suction hose	1
4	KM0407808B-04	Pressure valve (ball)	1	34+35+36	KM0407808B-33+34+35	screw M5X14 of engine	3	72	KM0407808B-72	Joint-L 22*33.5	1
5	KM0407808B-05	O' ring 14X1.9	1	37	KM0407808B-37	Bearing 608	1	73	KM0407808B-73	Drain plug	1
6	KM0407808B-06	Valve seat	1	38	KM0407808B-38	Gear with shaft	1	74	KM0407808B-74	O-ring 9X1.9	1
7	KM0407808B-07	Outlet chamber	1	39	KM0407808B-39	Bearing 6203	1	75	KM0407808B-75	O-ring G60X3.5	1
8	KM0407808B-08	High pressure hose	1	40	KM0407808B-40	Bearing 6200	1	76	KM0407808B-76	Crank case cover	1
9	KM0407808B-09	Nylon nut M6	1	41	KM0407808B-41	Oil inlet cup	1	77	KM0407808B-77	Screw M6X12	1
10	KM0407808B-10	washer ?	1	42	KM0407808B-42	O-ring 16X2	1	78	KM0407808B-78	O-ring 25X3	1
11	KM0407808B-11	Pressure adjusting	1	43	KM0407808B-43	Oil seal 18.28.8	1	78	KM0407808B-79	Oil glass	1
12	KM0407808B-12	Pressure valve screw	1	44	KM0407808B-44	O-ring 22x2.4	1	80	KM0407808B-80	nut(M6)	1
13	KM0407808B-13	O-ring 13X1.9	1	45	KM0407808B-45	Fixed plate	1	81	KM0407808B-81	washer	1
14	KM0407808B-14	Nut	1	46	KM0407808B-46	Grand	1	82	KM0407808B-82	line	1
15	KM0407808B-15	Relief valve Ass'y	1	47	KM0407808B-47	Adjusting ring	1	83	KM0407808B-83	Flex accelerator	1
16	KM0407808B-16	Screw M6X14	1	48	KM0407808B-48	V-packing upper seal	1	84	KM0407808B-84	Cable comp	1
17	KM0407808B-17	Spring	1	49	KM0407808B-49	V-packing	1	85	KM0407808B-85	cap of cord comp	1
18	KM0407808B-18	screw M6X16 with gasket	1	50+51	KM0407808B-50+51	Grease cup	2	86	KM0407808B-86	Cord comp	1
19	KM0407808B-19	Valve Ass'y(stainless)	1	52	KM0407808B-52	Clip-L	1	87	KM0407808B-87	nut(M6)	1
19-1	KM0407808B-19-1	Valve Box	1	53	KM0407808B-53	Suction hose(1.5m)	1	88	KM0407808B-88	frame(iron)	1
19-2	KM0407808B-19-2	Valve Spring	1	54	KM0407808B-54	cote of strainer	1	89	KM0407808B-89	feet	1
19-3	KM0407808B-19-3	Valve Flat	1	55	KM0407808B-55	strainer	1	90	KM0407808B-90	washer	1
19-4	KM0407808B-19-4	Valve Seat	1	56	KM0407808B-56	Screw M6X75	1	91	KM0407808B-91	screw	1
19-5	KM0407808B-19-5	Valve Seal	1	57	KM0407808B-57	Suction chamber	1	92	KM0407808B-92	plug	1
20	KM0407808B-20	Drum clutch	1	58	KM0407808B-58	Cylinder	1	93	KM0407808B-93	Engine part	1
21	KM0407808B-21	Drum case	1	59	KM0407808B-59	Packing seat	1				
22	KM0407808B-22	screw M6X16 with gasket	1	60	KM0407808B-60	V-packing(fabric)	1				
23	KM0407808B-23	Gasket	1	61	KM0407808B-61	Crank case	1				
24	KM0407808B-24	Oil seal 17X28X7	1	62	KM0407808B-62	Plunger 18MM	1				
25	KM0407808B-25	Steel pipe	1	63	KM0407808B-63	nut M6	1				
26	KM0407808B-26	O-ring 16X2	1	64	KM0407808B-64	screw M6X16 with gasket	1				
27	KM0407808B-27	Bearing 6201	1	65	KM0407808B-65	Outlet chamber	1				
28	KM0407808B-28	Shaft	1	66	KM0407808B-66	outlet hose(8.5mmx10m)	1				
29	KM0407808B-29	Bearing HK1010	1	67	KM0407808B-67	sprayer gun(30cm straight)	1				
30	KM0407808B-30	nut M6	1	68	KM0407808B-68	Suction chamber	1				